


BMV-1115, BMV-2115



BMV-1115

	CODE		CODE		CODE		CODE
1	402591000	7b	402085500	15b	450521000	23a	409011100
2	402595000	9	401023000	16	-----	23b	409000200
3	402501100	10	-----	17	450500070	24	407502100
4	401510000	11	407810500	18	450503500		
5a	401500500	12	-----	19	450500080		
5b	401509000	13	-----	20	450503000		
6	-----	14	500502501	21	450502000		
7a	402010500	15a	500501000	22	-----		



BMV-2115

	CODE		CODE		CODE		CODE
1	402591000	7b	402085500	15b	450530100	23a	409011100
2	402595000	9	401023000	16	-----	23b	409000200
3	402501100	10	-----	17	450500070	24	407502100
4	401510000	11	407810500	18	450503500		
5a	401500500	12	-----	19	450500080		
5b	401509000	13	-----	20	450503000		
6	-----	14	500502501	21	450511000		
7a	402010500	15a	500501500	22	-----		