


Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
+ 1	SL0841		Pusher	
2	SA1010		Hopper	
3	SL3011		Magnet	
4	SL3458		Flange	
5	SL2587	ø35xø52x11	Oil seal	
6	SL2548		Tap	
+ 7	SL2924		Knob	
8	SL3106	Stainless-steel	Sleeve	
8	SL3268	Unger	Sleeve	
+ 9	SA2300	Stainless-steel	Screw shaft	
9	SA2400	Unger	Screw shaft	
10	SL2520		Pivot	
10	SL2560	Unger	Pivot	
+ 11	////////		Cutter	
+ 12	////////		Plate	
13	SL2420	Stainless-steel	Handwheel	
14	SL3473		Housing	
+ 15	32W3240		Microswitch	
16	SL3247		Support	
17	SL3246		Bracket	
18	SL3183	230V/1Ph/50-60Hz	Fan	
19	SL3257		Net	
20	SL3233		Covering	
21	SL1668	PG11	Cable clamp	
22	SL1841	3Ph+Gnd	Electric cable	
22	SL1671	1Ph+N+Gnd	Electric cable	
23	SL3577		Label	
24	SA1083	Start-reverse	Push button	
25	SL0807	Stop	Push button	
26	MP0257	M22x1,5	Nut	
27	SL3459		Bracket	
28	SL3477		Gear box	

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
29	SL3457		Flange	
30	SL2588	51207	Bearing	
31	SL3463		Shaft	
32	SA1003	400V/3Ph/50Hz	Motor	
32	SL2894	230V/1Ph/50Hz	Motor	
33	SL3088	55µF	Condenser	
 34	SL0999		Electronic card	
35	SL3020		Spacer	
36	SL3460	Three-phase	Bottom	
36	SL3461R0	Single-phase	Bottom	
37	SL1610	Three-phase	Foot	
37	SL0235	Single-phase	Foot	
38	SL0247		Reversing gear	

