

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
+	1	CO4005	Foot	
	2	CO4559 (K300-330)	Bottom	
	2	CO4560 (K350-370)	Bottom	
	3	CO4561 (K300)	Bracket	
	4	CO4143 230V/1Ph/50-60Hz (K300)	Motor	
	4	CO4146 400V/3Ph/50-60Hz (K300)	Motor	
	4	CO4145 230V/1Ph/50-60Hz (K330-350-370)	Motor	
	4	CO4144 400V/3Ph/50-60Hz (K330-350-370)	Motor	
	5	CO4562	Bracket	
+	6	CO4563 TB2.34 510x10 (K300-330)	Belt	
+	6	CO4564 TB2.34 598x12 (K350-370)	Belt	
	7	CO4565	Plate	
	8	CO4566	Support	
	9	CO3971	Pivot	
	10	CO4061	Cam	
	11	CO4028	Washer	
+	13	CO3923 230V/1Ph/50-60Hz	Push button with card	
+	13	CO3924 400V/3Ph/50-60Hz	Push button with card	
	14	CO3943	Bracket	
	15	CO3942 8µF	Condenser	
	16	CO4567	Knob	
	17	CO3926 (K300-330) Assembly	Tool grinder	
	17	CO4568 (K350-370) Assembly	Tool grinder	
	18	CO4569 (K300-330)	Rod	
	18	CO4570 (K350-370)	Rod	
+	19	CO4571	Claw	
+	20	CO4572	Knob	
	21	CO4573 (K300-330)	Carriage	
	21	CO4574 (K350-370)	Carriage	
	22	CO4575	Shaft	
	23	CO4576	Support	
	24	CO4577 (K300)	Protection	

+: ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
24	CO4578	(K330)	Protection	
24	CO4579	(K350)	Protection	
24	CO4580	(K370)	Protection	
25	CO4581		Knob	
26	CO4582	(K300)	Insert	
26	CO4583	(K330)	Insert	
26	CO4584	(K350)	Insert	
26	CO4585	(K370)	Insert	
27	CO4586	(K300)	Sail	
27	CO4587	(K330)	Sail	
27	CO4588	(K350)	Sail	
27	CO4589	(K370)	Sail	
+	28	CO4590	(K300-330)	Tie rod
+	28	CO4591	(K350-370)	Tie rod
	29	CO4003	Knob	
	30	CO4556	(K300)	Support
	30	CO4002	(K330-350-370)	Support
	31	CO3995	(K300-330)	Pivot
	31	CO4592	(K350-370)	Pivot
+	32	CO3901	(K300-330)	Grinding wheel
+	32	CO0993	(K350-370)	Grinding wheel
	33	CO3999	(K300-330)	Pivot
	33	CO4593	(K350-370)	Pivot
	34	CO4000	(K300-330)	Pivot
	34	CO4594	(K350-370)	Pivot
	35	CO3996	Wheel pusher	
+	36	CO3900	(K300-330)	Deburring wheel
+	36	CO0992	(K350-370)	Deburring wheel
	37	CO4595	(K300-330)	Knob
	38	CO3998	(K350-370)	Covering
	38	CO4596	(350-370)	Covering
	39	CO3997	Spring	

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
40	CO4001	(K300-330)	Support	
40	CO4597	(K350-370)	Support	
41	CO4598	(K300-330)	Covering	
41	CO4599	(K350-370)	Covering	
42	CO4056		Spring	
43	CO4618		Plate	
44	CO4619		Support	
45	CO4620	(K300-330)	Shaft	
45	CO4621	(K350-370)	Shaft	
46	CO4622		Support	
47	CO4623		Spacer	
48	CO4624		Spacer	
49	CO4625	(K300-330)	Rod	
49	CO4626	(K350-370)	Rod	
50	CO4033	(K300)	Protection	
50	CO4067	(K330)	Protection	
50	CO4093	(K350)	Protection	
50	CO4557	(K370)	Protection	
51	CO4034	(K300)	Plate	
51	CO4068	(K330)	Plate	
51	CO4094	(K350)	Plate	
51	CO4558	(K370)	Plate	
52	CO4627		Pivot	
53	CO4069		Pulley	
54	SL0073	6004 ZZ	Bearing	
55	CO4628		Spacer	
56	CO4629	(K300-330)	Base	
56	CO4630	(K350-370)	Base	
57	CO4032	(K300)	Ring	
57	CO4066	(K330)	Ring	
57	CO4091	(K350)	Ring	
57	CO4497	(K370)	Ring	

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
58	CO3922	(K300)	Blade	
58	CO4050	(K330)	Blade	
58	CO2763	(K350)	Blade	
58	CO2764	(K370)	Blade	
59	CO4031	(K300)	Blade cover	
59	CO4065	(K330)	Blade cover	
59	CO4090	(K350)	Blade cover	
59	CO4496	(K370)	Blade cover	
60	CO3978		Pivot	
61	CO4631		Pivot	
62	CO4632		Rod	
63	CO4633		Ram	
64	CO4634		Spacer	
65	CO4635		Holder	
+	66	CO4636	Protection	
+	67	CO4637	Knob	
68	CO4638		Support	
69	CO4639	(K300-330)	Salami carriage	
69	CO4640	(K350-370)	Salami carriage	
70	CO4641		Handle	
71	CO4642		Cam	
72	CO4643		Ring	
73	CO4680	626 ZZ	Bearing	
74	CO4644		Rod	
75	CO4645		Plate	
76	CO4646		Bush	
77	CO4647		Spring	
78	CO4648	(K300-330)	Rod	
78	CO4649	(K350-370)	Rod	
79	CO4650	(K300-330)	Plate	
79	CO4651	(K350-370)	Plate	
80	CO4652		Pivot	

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
81	CO4681	608 ZZ	Bearing	
82	CO4653		Support	
83	CO4654		Bracket	
84	CO4800	(K300-330)	Plate	
84	CO4655	(K350-370)	Plate	
85	CO4656		Spacer	
86	CO4657		Pad	
87	CO4658		Pad	
88	CO4659		Bush	
89	CO4660		Lever	
90	CO4661		Pivot	
91	CO4662	(K300-330)	Rod	
91	CO4663	(K350-370)	Rod	
+ 92	CO4016		Handle	
93	CO4664		Spacer	
94	CO4665	(K300-330)	Carriage	
94	CO4666	(K350-370)	Carriage	
95	CO4667		Pivot	
96	CO4668		Ram	
97	CO4669	(K300-330)	Carriage	
97	CO4670	(K350-370)	Carriage	
98	CO4671		Bush	
99	CO4672		Protection	
100	CO4673	(K300-330)	Support	
101	CO4674	(K350-370)	Support	
102	CO4675	(K300-330) Assembly	Salami carriage	
102	CO4676	(K350-370) Assembly	Salami carriage	
103	CO4677	(K300-330) Assembly	Meat carriage	
103	CO4678	(K350-370) Assembly	Meat carriage	
104	SL0075	ø20	Seeger	
105	SL2056	ø42	Seeger	
108	CO0415		Pivot	



K/300 - K/330 - K/350 - K/370

T0001 **00**

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
109	SL0271	608H ZZ	Bearing	
124	CO4802	Assembly	Holder	

