


Crepiera elettrica mod.CRP-CRP2
Electric crepiere mod.CRP-CRP2



CREPIERA ELETTRICA MOD.CRP-CRP2 ELECTRIC CREPIERE MOD.CRP-CRP2

Rif No	Codice Code		Caratteristiche Characteristics	Descrizione Description	
1	CO1937			Disco	Disk
2	CO1765	☺	230V/1Ph/50-60Hz	Resistenza	Resistance
3	CO1938			Isolante	Insulating material
4	CO1939		Stainless steel	Spatola	Spatula
5	CO1940		Wood	Spatola	Spatula
6	32D0360			Pressacavo	Cable clamp
7	CO1941	☺		Termostato	Thermostat
8	CO1942	☺		Termostato	Thermostat
9	CO1943			Interruttore	Switch
10	CO1944		CRP	Carcassa	Housing
10	CO1945		CRP2	Carcassa	Housing
11	CO1946			Piedino	Foot
12	32W2970		230V 2W	Lampada	Lamp
13	CO1947			Pomello	Knob
14	CO1948		230V 2W	Lampada	Lamp
(*) : fuori produzione / out of production			☺ : ricambio consigliato / spare part suggested		

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
1	CO1937	(CRP-CRP2)	Disk	
1	CO4707	(CRP4-CRP42)	Disk	
 2	CO1765	(CRP-CRP2)	Resistance	
 2	CO3676	(CRP4-CRP42)	Resistance	
3	CO1938		Insulating material	
4	CO1939	Stainless steel (CRP-CRP2)	Spatula	
4	CO0922	Stainless steel (CRP4-CRP42)	Spatula	
5	CO1940	Wood	Spatula	
6	32D0360		Cable clamp	
 7	CO5106		Thermostat	
7	CO1941	20/09/10 f.p.(*)	Thermostat	
 8	CO1942		Thermostat	
9	SA1097	20/09/10 f.p.(*)	Switch	
10	CO1944	(CRP)	Housing	
10	CO1945	(CRP2)	Housing	
10	CO2937	(CRP4)	Housing	
10	CO3189	(CRP42)	Housing	
11	CO1946		Foot	
12	32W2970	230V 2W	Lamp	
13	SL3550		Knob	
17	CO0270		Terminal box	
18	SL3975	(CRP)	Label	
18	SL3658	20/09/10 f.p.(*) - (CRP)	Label	
18	SL3976	(CRP2)	Label	
18	SL3659	20/09/10 f.p.(*) - (CRP2)	Label	
18	SL3977	(CRP4)	Label	
18	SL3660	20/09/10 f.p.(*) - (CRP4)	Label	
18	SL3978	(CRP42)	Label	
18	SL3661	20/09/10 f.p.(*) - (CRP42)	Label	
19	CO1943	01/01/08 f.p.(*)	Switch	
20	CO5107		Lamp	

