




**Snackgeräte
Teller-Wärmeschrank**

Artikel-Nr. 271006
(OTS-78)

Explosionszeichnung / Ersatzteile

OTS-78



OTS-78

	CODE		CODE		CODE		CODE
1	453500610	11	401500550	21	453500140		
2	453500620	12	402591000	22	453500150		
3	453500160	13	453500690	23	453500170		
4	402010000	14	502510170	24	401040750		
5	402085500	15	502510130A	25	453500730		
6	407502137	16	502510140A	26	453500430		
7	502510150	17	453500680	27			
8	453500700	18	502510190				
9	402501100	19	453500640				
10	402595000	20	407810500				