


FP-36 R, FP-66 R



FP-36 R

	CODE		CODE		CODE		CODE
1a	402593000	8	-----	17	-----	24d	407502121
1b	402590770	9	401031000	18	450503500	25	-----
2	402595001	10	407803000	19	504500240	26	454500580
3	402503000	11	407810000	20	-----	27	504500220
4a	401515100	12	-----	21	504500260		
4b	401515200	13	-----	22	454500440		
5	401550010	14	-----	23	454500480		
6	-----	15a	454500380	24a	407502115		
7a	402010500	15b	454500400	24b	407502120		
7b	402085500	16	407600100	24c	407502116		



FP-66 R

	CODE		CODE		CODE		CODE
1a	402593000	8	-----	17	-----	24d	407502121
1b	402590770	9	401031000	18	450503500	25	-----
2	402595001	10	407803000	19	504500400	26	454500580
3	402503000	11	407810000	20	-----	27	504500380
4a	401515100	12	-----	21	504500260		
4b	401515200	13	-----	22	454500820		
5	401550010	14	-----	23	454500860		
6	-----	15a	454500760	24a	407502115		
7a	402010500	15b	454500780	24b	407502120		
7b	402085500	16	407600100	24c	407502116		