


Drawing



HVA\HVM

Spare parts list

POS.	PCS	Part No.	Description
1	1	1304061	Lid plastic HVA
2	1	1031301	HVA lid
3	1	1304062	Top plastic HVA
4	1	160970	CQ sticker
5	1	1802120	Connection faucet short
6	1	120200-02	Faucet metal black top
7	1	1031641	Electronic unit PCB HVA
8	1	1603853	Membrane switch HVA
9	1	253207	Drip tray insert
10	1	1304063	Drip tray HVA
11	1	220221	High limit switch short with connect
12	1	1206589	Gasket tank
13	1	1205303	Sensor HVA tall(160mm)
14	1	1205302	Sensor short (55mm)
15	1	1505042	Inlet hose 3/4"-1/2"
16	1	1206604	Gasket DIA18mm x 9mm D2mm
17	1	1206603	Gasket DIA23.5mm x 15mm D3mm
18	1	2760094	Gasket set for inlet hose
19	1	120422	Air vent
20	2	1402150	Screw T20 M4x8mm
21	4	1401101-01	Nut M3
22	2	1461008	Spring washer M3
23	1	1605362	Double seal level sensor
24	1	1203527	Tank complete HVA
25	1	1206507	Fiber washer
26	1	1601311	Element 2200W/230V with SS nuts
27	1	1605361	Seal NTC
28	1	1206123	Non return valve
29	3	140330	Clamp 13.3mm
30	Sale in M	150501	Silicon hose 8X12mm
31	1	1403400	PP plug for drainage hose
32	1	1206581	Seal solid state
33	1	1604203/1604201	Solid state 25A
34	4	120320	Rubber feet V2
35	1	1402163	Screw T20 M4x8mm
36	1	1403401	Inlet valve plug with silicon seal
37	1	160801-04	Rocker switch single
38	1	160571	Emi fliter with AC socket
39	1	120624-01	Single valve 2.5L/min
40	1	711000	NTC thermistor belong
41	1	160565	Power cord european 16A250V