


DM-4

Drawing



DM-4

Spare parts list

POS.	PCS	Part No.	Description
1	1	I20433	Decanter lid
2	4	I10001	Decanter CQ glass
3	2	I204012	Lid of tank original
4	2	I204013	Strainer
5	2	I102016	Brew basket 1.8L 90 mm
6	2	I204015	Water tank complete 1.8L
7	2	I505041	Silicon hose hot 1.8L
8	2	I20422	Air inlet plastic 1.8L
9	12	I402150	Screw T20,M4X8
10	2	I60212-03	Over heating protection
11	1	I605651	PG complete (PG16)
12	1	I605210	Power cable 4 x 1.5mm
13	2	I031503	Silicon hose cold complete
14	4	I40339	Clip for hose 16.4mm
15	2	I205101	Brewing elemnet 230V/2200W
16	2	I505062	Overflow tube
17	1	I206123	Non return valve
18	1	I60549	Connector fv122
19	2	I204016	Spray nozzle for water tank
20	6	I60536	Gasket rubber NBR(Rubber Trp 30.0)
21	2	I204014	Microswitch holder
22	2	I60821	Micro switch tank 1.8L
23	2	I505063	Bottom cover rubber
24	4	I20320	Rubber feetV2
25	4	I402163	Screw M4x8
26	4	I20811	Warming plate 230V/95W
27	1	I60101	Heat coil 95W
28	1	I603855	Overlay original M
29	1	I60804-04	Brewing lamp
30	1	I60802-04	Rocker switch double