

LISTA RICAMBI IMPASTATRICI IMR-ITR

INGLESE									
RIF.	DESCRIPTION	CODICE							
		IMR 5	IMR 10	IMR/ITR 15	IMR/ITR 20	IMR/ITR 30	IMR/ITR 40	IMR/ITR 50	
1	MIXER FRAME	7T010026	7T010026	7T010100	7T010100	7T010110	7T010120	7T010120	
2	BACK PANEL	4P040559	4P040559	4P040655	4P040655	4P040656	4P040657	4P040657	
3	TOP LID	4P040554	4P040554	4P040650	4P040650	4P040651	4P040652	4P040652	
4	BEARINGS	5C030012	5C030012	5C030012	5C030012	5C030012	5C030012	5C030012	
5	EXTRACTABLE BOWL	5V010512	5V010510	5V010514	5V010505	5V010506	5V010507	5V010508	
6	BOWL SUPPORT	7S010018	7S010018	7S010018	7S010018	7S010019	7S010019	7S010020	
7	KEY	5L500035	5L500035	5L500040	5L500040	5L500040	5L500040	5L500040	
8	KEY	5L500039	5L500039	5L500039	5L500039	5L500039	5L500039	5L500039	
9	RING GEAR	5C030503	5C030503	5C030501	5C030501	5C030500	5C030500	5C030500	
10	HUB CROWN	4F050010	4F050010	4F050010	4F050010	4F050010	4F050010	4F050010	
11	FLAT WASHER	5R500020	5R500020	5R500020	5R500020	5R500020	5R500020	5R500020	
12	M8 SCREW	5V500057	5V500057	5V500057	5V500057	5V500057	5V500057	5V500057	
13	BOWL SUPPORT CHAIN	5C020109	5C020109	5C020100	5C020100	5C020101	5C020102	5C020102	
14	SPIRAL SUPPORT	3S010100	3S010100	7S010000	7S010000	7S010001	7S010002	7S010001	
15/A	BEARINGS	5C030014	5C030014	5C030011+ 5S500100	5C030011+ 5S500100	5C030013+ 5S500110	5C030013+ 5S500110	5C030013+ 5S500110	
15/B	BEARINGS	5C030014	5C030014	5C030010+ 5S500100	5C030010+ 5S500100	5C030011+ 5S500100	5C030011+ 5S500100	5C030011+ 5S500100	
16	FLAT WASHER	-	-	5R500027	5R500027	5R500020	5R500020	5R500020	
17	T.E. SCREW	-	-	5V500003	5V500003	5V500057	5V500057	5V500057	
19	KEY	-	-	5L500035	5L500035	5L500035	5L500035	5L500035	
20	SPIRAL	5S080004	5S080004	5S080000	5S080000	5S080001	5S080001	5S080003	
21	DOUGH BREAKER	4S010503	4S010503	4S010500	4S010500	4S010501	4S010502	4S010502	
22	SPIRAL CHAIN	5C020110	5C020110	5C020107	5C020105	5C020105	5C020107	5C020107	
23	UCF SUPPORT	5S030009	5S030009	5S030010	5S030010	5S030010	5S030010	5S030010	
24	SUP. PINION. TRANSM. SHAFT	5P030009	5P030010	5P030000	5P030000	5P030001	5P030001	5P030001	
25	TRANSMISSION SHAFT	3A050519	3A050519	3A050520	3A050520	3A050521	3A050522	3A050522	
26	INF. PINION TRANSM. SHAFT	5P030008	5P030008	5P030005	5P030005	5P030006	5P030006	5P030006	
27	ELASTIC PLUG, HEAVY TYPE	5G510002	5G510002	5S100102	5S100102	5S100101	5S100101	5S100101	
28	KEY	5L500001	5L500001	5L500033	5L500033	5L500033	5L500033	5L500033	

RIF.	DESCRIPTION	CODICE								
		IMR 5	IMR 10	IMR/ITR 15	IMR/ITR 20	IMR/ITR 30	IMR/ITR 40	IMR/ITR 50		
29-30	THREE PHASE GEAR MOTOR	5M010010	5M010010	5M010501	5M010501	5M010506	5M010506	5M010511		
29-30	SINGLE PHASE GEAR MOTOR	-	-	5M010500	5M010500	5M010505	5M010505	5M010510		
29-30	THREE PHASE GEAR MOTOR 2 SPEEDS	-	-	5M010502	5M010502	5M010507	5M010507	5M010512		
31	SINGLE PHASE SWITCH	5I000040	5I000040	5I100040	5I100040	5I100040	5I100040	5I100040		
31	THREE PHASE SWITCH	-	-	5I100030	5I100030	5I100030	5I100030	5I100030		
32	TIMER	5T010301	5T010301	5T010301	5T010301	5T010301	5T010301	5T010301		
33	CASTORS	8K010001	8K010001	8K010001	8K010001	8K010001	8K010001	8K010001		
34	TOP PISTON	5M500020	5M500020	5M500020	5M500020	5M500020	5M500020	5M500020		
35	UNIT (FOR 2 SPEEDS VERSION)	-	-	5S010052	5S010052	5S010052	5S010052	5S010052		
36	SINGLE PHASE GEAR CABLE	-	-	7C010023	7C010023	7C010023	7C010023	7C010023		
36	THREE PHASE GEAR CABLE	-	-	7C010022	7C010022	7C010022	7C010022	7C010022		
37	PROTECTION GRID	5G080004	5G080004	5G080000	5G080000	5G080001	5G080002	5G080002		
38	GRID SHAFT	3A010504	3A010504	3A010500	3A010500	3A010501	3A010502	3A010502		
39	T.E. SCREW	5V500022	5V500022	5V500023	5V500023	5V500023	5V500023	5V500023		
40	SPACER	3D010051	3D010051	3D010050	3D010050	3D010050	3D010050	3D010050		
41	MICRON SUPPORT GRID	4S060501	4S060501	4S060504	4S060504	4S060504	4S060504	4S060504		
42	MICRO GRID	5M050500	5M050500	5M050500	5M050500	5M050500	5M050500	5M050500		
43	SPIRAL PINION	5P030007	5P030007	5P030010	5P030010	5P030011	5P030011	5P030011		
44	BRACKET	4I010025	4I010025	4I010026	4I010026	4I010027	4I010027	4I010027		
45	BLOCK TOP HANDLE	5M200035	5M200035	5M200035	5M200035	5M200035	5M200035	5M200035		
46	TOP MICRON	5M050501	5M050501	5M050501	5M050501	5M050501	5M050501	5M050501		
47	PROTECTION	4P020504	4P020504	4P020505	4P020505	4P020506	4P020506	4P020507		
48	BLOCK BOWL PIN	3P030005	3P030005	3P030005	3P030005	3P030005	3P030005	3P030005		
49	SUP. DISK BOWL	4D020531	4D020531	4D020530	4D020530	4D020530	4D020530	4D020530		
50	BLOCK DISK BOWL	4D020523	4D020523	4D020520	4D020520	4D020521	4D020522	4D020522		
51	DISK GASKET	5G50003	5G50003	5G50003	5G50003	5G50003	5G50003	5G50003		
52	SENSOR SUPPORT	4S000025	4S000025	4S000025	4S000025	4S000025	4S000025	4S000025		
53	PROXIMITY SENSOR	5S010075	5S010075	5S010075	5S010075	5S010075	5S010075	5S010075		
54	TOP PIN	-	-	-	-	-	-	-		
55	TOP TRANSMISSION SHAFT	3A050524	3A050524	3A050525	3A050525	3A050525	3A050525	3A050525		
56	TOP SHAFT PLUG	5S510015	5S510015	5S510015	5S510015	5S510015	5S510015	5S510015		
57	TRANSMISSION JOINT	5G010009	5G010009	5G010006	5G010006	5G010006	5G010006	5G010006		
58	KEY	5L500035	5L500035	5L500040	5L500040	5L500040	5L500040	5L500040		

