

LISTA RICAMBI IMPASTATRICI IMR-ITR

RIF.	DESCRIPTION	INGLESE						
		CODICE						
		IMR 5	IMR 10	IMR/ITR 15	IMR/ITR 20	IMR/ITR 30	IMR/ITR 40	IMR/ITR 50
1	MIXER FRAME	7T010026	7T010026	7T010100	7T010100	7T010110	7T010120	7T010120
2	BACK PANEL	4P040559	4P040559	4P040655	4P040655	4P040656	4P040657	4P040657
3	TOP LID	4P040554	4P040554	4P040650	4P040650	4P040651	4P040652	4P040652
4	BEARINGS	5C030012	5C030012	5C030012	5C030012	5C030012	5C030012	5C030012
5	EXTRACTABLE BOWL	5V010512	5V010510	5V010514	5V010505	5V010506	5V010507	5V010508
6	BOWL SUPPORT	7S010018	7S010018	7S010018	7S010018	7S010019	7S010019	7S010020
7	KEY	5L500035	5L500035	5L500040	5L500040	5L500040	5L500040	5L500040
8	KEY	5L500039	5L500039	5L500039	5L500039	5L500039	5L500039	5L500039
9	RING GEAR	5C030503	5C030503	5C030501	5C030501	5C030500	5C030500	5C030500
10	HUB CROWN	4F050010	4F050010	4F050010	4F050010	4F050010	4F050010	4F050010
11	FLAT WASHER	5R500020	5R500020	5R500020	5R500020	5R500020	5R500020	5R500020
12	M8 SCREW	5V500057	5V500057	5V500057	5V500057	5V500057	5V500057	5V500057
13	BOWL SUPPORT CHAIN	5C020109	5C020109	5C020100	5C020100	5C020101	5C020102	5C020102
14	SPIRAL SUPPORT	3S010100	3S010100	7S010000	7S010000	7S010001	7S010002	7S010001
15/A	BEARINGS	5C030014	5C030014	5C030011+ 5S500100	5C030011+ 5S500100	5C030013+ 5S500110	5C030013+ 5S500110	5C030013+ 5S500110
15/B	BEARINGS	5C030014	5C030014	5C030010+ 5S500100	5C030010+ 5S500100	5C030011+ 5S500100	5C030011+ 5S500100	5C030011+ 5S500100
16	FLAT WASHER	-	-	5R500027	5R500027	5R500020	5R500020	5R500020
17	T.E. SCREW	-	-	5V500003	5V500003	5V500057	5V500057	5V500057
19	KEY	-	-	5L500035	5L500035	5L500035	5L500035	5L500035
20	SPIRAL	5S080004	5S080004	5S080000	5S080000	5S080001	5S080001	5S080003
21	DOUGH BREAKER	4S010503	4S010503	4S010500	4S010500	4S010501	4S010502	4S010502
22	SPIRAL CHAIN	5C020110	5C020110	5C020107	5C020105	5C020105	5C020107	5C020107
23	UCF SUPPORT	5S030009	5S030009	5S030010	5S030010	5S030010	5S030010	5S030010
24	SUP. PINION. TRANSM. SHAFT	5P030009	5P030010	5P030000	5P030000	5P030001	5P030001	5P030001
25	TRANSMISSION SHAFT	3A050519	3A050519	3A050520	3A050520	3A050521	3A050522	3A050522
26	INF. PINION TRANSM. SHAFT	5P030008	5P030008	5P030005	5P030005	5P030006	5P030006	5P030006
27	ELASTIC PLUG, HEAVY TYPE	5G510002	5G510002	5S100102	5S100102	5S100101	5S100101	5S100101
28	KEY	5L500001	5L500001	5L500033	5L500033	5L500033	5L500033	5L500033

RIF.	DESCRIPTION	CODICE						
		IMR 5	IMR 10	IMR/ITR 15	IMR/ITR 20	IMR/ITR 30	IMR/ITR 40	IMR/ITR 50
29-30	THREE PHASE GEAR MOTOR	5M010010	5M010010	5M010501	5M010501	5M010506	5M010506	5M010511
29-30	SINGLE PHASE GEAR MOTOR	-	-	5M010500	5M010500	5M010505	5M010505	5M010510
29-30	THREE PHASE GEAR MOTOR 2 SPEEDS	-	-	5M010502	5M010502	5M010507	5M010507	5M010512
31	SINGLE PHASE SWITCH	5I00040	5I00040	5I100040	5I100040	5I100040	5I100040	5I100040
31	THREE PHASE SWITCH	-	-	5I100030	5I100030	5I100030	5I100030	5I100030
32	TIMER	5T010301	5T010301	5T010301	5T010301	5T010301	5T010301	5T010301
33	CASTORS	8K010001	8K010001	8K010001	8K010001	8K010001	8K010001	8K010001
34	TOP PISTON	5M500020	5M500020	5M500020	5M500020	5M500020	5M500020	5M500020
35	UNIT (FOR 2 SPEEDS VERSION)	-	-	5S010052	5S010052	5S010052	5S010052	5S010052
36	SINGLE PHASE GEAR CABLE	-	-	7C010023	7C010023	7C010023	7C010023	7C010023
36	THREE PHASE GEAR CABLE	-	-	7C010022	7C010022	7C010022	7C010022	7C010022
37	PROTECTION GRID	5G080004	5G080004	5G080000	5G080000	5G080001	5G080002	5G080002
38	GRID SHAFT	3A010504	3A010504	3A010500	3A010500	3A010501	3A010502	3A010502
39	T.E. SCREW	5V500022	5V500022	5V500023	5V500023	5V500023	5V500023	5V500023
40	SPACER	3D010051	3D010051	3D010050	3D010050	3D010050	3D010050	3D010050
41	MICRON SUPPORT GRID	4S060501	4S060501	4S060504	4S060504	4S060504	4S060504	4S060504
42	MICRO GRID	5M050500	5M050500	5M050500	5M050500	5M050500	5M050500	5M050500
43	SPIRAL PINION	5P030007	5P030007	5P030010	5P030010	5P030011	5P030011	5P030011
44	BRACKET	4L010025	4L010025	4L010026	4L010026	4L010027	4L010027	4L010027
45	BLOCK TOP HANDLE	5M200035	5M200035	5M200035	5M200035	5M200035	5M200035	5M200035
46	TOP MICRON	5M050501	5M050501	5M050501	5M050501	5M050501	5M050501	5M050501
47	PROTECTION	4P020504	4P020504	4P020505	4P020505	4P020506	4P020506	4P020507
48	BLOCK BOWL PIN	3P030005	3P030005	3P030005	3P030005	3P030005	3P030005	3P030005
49	SUP. DISK BOWL	4D020531	4D020531	4D020530	4D020530	4D020530	4D020530	4D020530
50	BLOCK DISK BOWL	4D020523	4D020523	4D020520	4D020520	4D020521	4D020522	4D020522
51	DISK GASKET	5G50003	5G50003	5G50003	5G50003	5G50003	5G50003	5G50003
52	SENSOR SUPPORT	4S000025	4S000025	4S000025	4S000025	4S000025	4S000025	4S000025
53	PROXIMITY SENSOR	5S010075	5S010075	5S010075	5S010075	5S010075	5S010075	5S010075
54	TOP PIN	-	-	-	-	-	-	-
55	TOP TRANSMISSION SHAFT	3A050524	3A050524	3A050525	3A050525	3A050525	3A050525	3A050525
56	TOP SHAFT PLUG	5S510015	5S510015	5S510015	5S510015	5S510015	5S510015	5S510015
57	TRANSMISSION JOINT	5G010009	5G010009	5G010006	5G010006	5G010006	5G010006	5G010006
58	KEY	5L500035	5L500035	5L500040	5L500040	5L500040	5L500040	5L500040

